

Laser class 2
in acc. with IEC 60825-1

www.disto.com



SAP. No. 812 796a

Change Units

Switch between the following units:



0.000 m	0.00 ft
0.0000 m	0'00" 1/32
2 sec	0 in 1/32

Bluetooth®



1 × send
2 sec deactivate/activate

Quick Start

Leica DISTO™ D110




- 1 — ON/DIST
- 2 — Area
- 3 — Bluetooth®
- 4 — Clear/Off

- when it has to be **right**

Leica
Geosystems

Insert Batteries



Operation



1x → ON

CLEAR
OFF


2 sec → OFF



1x



Attach/Remove Clip



Area

