




Laser class 2
in acc. with IEC 60825-1

www.disto.com



SAP. No. 792 313b

Insert batteries




Operation



ON Measure OFF


Endpiece



Overview


- 1 Status Bar/Level
- 2 Reference
- 3 Active Function
- 4 Main Line (Result)
- 5 Selection keys linked to the symbol above
- 6 ON/DIST
- 7 Pointfinder (viewscreen)
- 8 Function Screen
- 9 Navigation
- 10 Clear/Off
- 11 Add/Subtract

Unlock keypad



Quick Start


Leica DISTO™ D510




- when it has to be **right**

Leica
Geosystems


(Navigate) Functions




? Helpfunctions




Reference/tripod




Settings




More results



Memory



Pointfinder



Personalized favorites

